



**NOTES:**

1. THE MACHINE SLICED METHOD (THIS DETAIL) IS THE STANDARD SILT FENCE INSTALLATION METHOD.
2. WIRE BACKED (ERO-1B) OR HEAVY DUTY (ERO-1C) SILT FENCE INSTALLATION METHODS SHOULD ONLY BE USED WHEN APPROVED OR DIRECTED BY THE CITY.
3. FOR CRITICAL AREAS ADJACENT TO WETLANDS OR BELOW LONG AND/OR STEEP SLOPES, STEEL POSTS ARE NECESSARY AS INDICATED ON THE PLANS.

**(A) COMPACTION:**  
 AFTER "SLICING" IN THE FABRIC AND *BEFORE* INSTALLATION OF STEEL OR WOOD POSTS, DRIVE INSTALLATION EQUIPMENT OVER THE "SLICE" WHILE FABRIC IS LAYING ON THE GROUND. *THEN* INSTALL THE POSTS AND PULL UP FABRIC TO ATTACH AT A UNIFORM HEIGHT.



**SILT FENCE  
 MACHINE SLICED**

LAST REVISION:  
 JUNE 2009

PLATE NO.  
 ERO-1